# **Up/Down Counting Pulse Indicator**

#### Measure High-speed Up/down Pulses with this Up/down Pulse Meter.

• Perfect for Measuring Rotary Encoder and ON/OFF Pulse Signals at High Speed

Cumulative pulse input is 50 kHz, quadrature pulse inputs are 25 kHz, and up/down pulse inputs are 30 kHz.

Note: No-voltage contacts of up to 30 Hz are supported.

• The count value can be converted to any value.

The length equivalent for any pulse can be set to any desired value.

This is effective for feed amount and position monitor displays.



Refer to Common Precautions on page 30.



## **Model Number Structure**

## ■ Model Number Legend

Base Units and Optional Boards can be ordered individually or as sets.

#### **Base Units**

## K3HB-C

1. Input Sensor Codes

NB: NPN input/voltage pulse input PB: PNP input

5. Supply Voltage

100-240 VAC: 100 to 240 VAC 24 VAC/VDC: 24 VAC/VDC

## Optional Board

Sensor Power Supply/Output Boards

K33-

**Relay/Transistor Output Boards** 

K34-

**Event Input Boards** 

K35-

## **Base Units with Optional Boards**

КЗНВ-С	; .	-			
	1	2	3	4	5

2. Sensor Power Supply/Output Type Codes

None: None

Relay output (PASS: SPDT) + Sensor power supply

(12 VDC±10%, 80 mA) (See note 1.)

L1A: Linear current output (DC0(4)-20 mA) + Sensor power supply

(12 VDC±10%, 80 mA) (See note 2.)

L2A: Linear voltage output (DC0(1)-5 V, 0 to 10 V) + Sensor power supply

(12 VDC±10%, 80 mA) (See note 2.)

Sensor power supply (12 VDC ±10%, 80 mA)

FLK1A: Communications (RS-232C) + Sensor power supply

(12 VDC±10%, 80 mA) (See note 2.)

FLK3A: Communications (RS-485) + Sensor power supply (12 VDC±10%, 80 mA) (See note 2.)

3. Relay/Transistor Output Type Codes

None: None

C1: Relay contact (H/L: SPDT each)

Relay contact (HH/H/LL/L: SPST-NO each) C2:

T1: Transistor (NPN open collector: HH/H/PASS/L/LL)

Transistor (PNP open collector: HH/H/PASS/L/LL)

BCD: BCD output + transistor output (NPN open collector: HH/H/PASS/L/LL)

DRT: DeviceNet (See note 2.)

#### 4. Event input Type Codes

None: None

5 points (M3 terminal blocks) NPN open collector

8 points (10-pin MIL connector) NPN open collector

5 points (M3 terminal blocks) PNP open collector 3:

8 points (10-pin MIL connector) PNP open collector

Note: 1. CPA can be combined with relay outputs only.

2. Only one of the following can be used by each Digital Indicator: RS-232C/RS-485 communications, a linear output, or DeviceNet communications.

## Accessories (Sold Separately)

K32-DICN: Special Cable (for event inputs with 8-pin connector)

K32-BCD: Special BCD Output Cable

## **Specifications**

## **■** Ratings

Supply voltage		100 to 240 VAC, 24 VAC/VDC, DeviceNet power supply: 24 VDC			
Allowable power supply voltage range		85% to 110% of the rated power supply voltage, DeviceNet power supply: 11 to 25 VDC			
Power consump (See note 1.)	otion	100 to 240 VAC: 18 VA max. (max. load) 24 VAC/DC: 11 VA/7 W max. (max. load)			
Current consun	nption	DeviceNet power supply: 50 mA max. (24 VDC)			
Input		No-voltage, voltage pulse, open collector			
External power	supply	12 VDC±10% 80 mA			
Event inputs	Hold input	NPN open collector or no-voltage contact signal			
	Reset input	ON residual voltage: 2 V max. ON current at 0 Ω: 4 mA max.			
	Bank input	Max. applied voltage: 30 VDC max.  OFF leakage current: 0.1 mA max.			
Output ratings Relay output (depends on		250 VAC, 30 VDC, 5 A (resistive load) Mechanical life expectancy: 5,000,000 operations, Electrical life expectancy: 100,000 operations			
the model)	Transistor output	Maximum load voltage: 24 VDC, Maximum load current: 50 mA, Leakage current: 100 μA max.			
Linear output		Linear output 0 to 20 mA DC, 4 to 20 mA: Load: $500 \Omega$ max, Resolution: Approx. 10,000, Output error: $\pm 0.5\%$ FS Linear output 0 to 5 VDC, 1 to 5 VDC, 0 to 10 VDC: Load: $5 k\Omega$ max, Resolution: Approx. 10,000, Output error: $\pm 0.5\%$ FS (1 V or less: $\pm 0.15$ V; not output for 0 V or less)			
Display method		Negative LCD (backlit LED) display 7-segment digital display (Character height: PV: 14.2 mm (green/red); SV: 4.9 mm (green))			
Main functions		Scaling function, measurement operation selection, output hysteresis, output OFF delay, output test, display value selection, display color selection, key protection, bank selection, display refresh period, maximum/minimum hold, reset			
Ambient operat	ing temperature	−10 to 55°C (with no icing or condensation)			
Ambient operat	ing humidity	25% to 85%			
Storage temper	ature	-25 to 65°C (with no icing or condensation)			
Altitude		2,000 m max.			
Accessories		Watertight packing, 2 fixtures, terminal cover, unit stickers, instruction manual. DeviceNet models also include a DeviceNet connector (Hirose HR31-5.08P-5SC(01)) and crimp terminals (Hirose HR31-SC-121) (See note 3.)			

- Note: 1. DC power supply models require a control power supply capacity of approximately 1 A per Unit when power is turned ON. Particular attention is required when using two or more DC power supply models. The OMRON S8VS-series DC Power Supply Unit is
  - 2. For K3HB-series DeviceNet models, use only the DeviceNet Connector included with the product. The crimp terminals provided are for Thin Cables.

## **■** Characteristics


Display range		-19,999 to 99,999	)						
Measurement range	)	Functions F1, F2: ±2 gigacounts							
			0 to 4 gig						
Input signals		No-voltage contact (30 Hz max. with ON/OFF pulse width of 15 ms min.)							
		Voltage pulse	Mode	Input frequency range	ON/OFF pulse width	ON voltage OFF voltage		Input impedance	
			F1	0 to 30 kHz	16 μs min.	4.5 to 30 V	-30 to 2 V	10 kΩ	
			F2	0 to 25 kHz	20 μs min.				
			F3	0 to 50 kHz	9 μs min.				
		Open collector	Mode	Input frequency range	ON/OFF pulse width	Note: The			
			F1	0 to 30 kHz	16 μs min.	Mete	er will malfunction that the inp	on it a pulse	
			F2	0 to 25 kHz	20 μs min.	rang	e is input. SYŚ	ERR may	
			F3	0 to 50 kHz	9 μs min.	appe	ear on the displ	ay.	
Connectable senso	rs	ON residual voltaç							
		OFF leakage curre				A = u   b   e   b = u			
		Load current:		have a switching of be able to properly			or less.		
Max. No. of display		5 (-19999 to 9999							
Comparative outputime	t response		parativė c	it; 10 ms max.: Rel output is made whe			nge in the input	signal from 15%	
Linear output respo	onse time			nal analog output v % or 95% to 15%)	/alue is reache	d when there is	a forced sudde	n change in the	
Insulation resistance	e	20 M $\Omega$ min. (at 50	0 VDC)						
Dielectric strength		2,300 VAC for 1 m	nin betwee	en external termina	ls and case				
Noise immunity		100 to 240 VAC models:  ±1,500 V at power supply terminals in normal or common mode (waveform with 1-ns rising edge and pulse width of 1 μs/100 ns)  24 VAC/VDC models:  ±1,500 V at power supply terminals in normal or common mode (waveform with 1-ns rising edge and pulse width of 1 μs/100 ns)							
Vibration resistance	e			celeration: 50 m/s <sup>2</sup>	•	· · · · · · · · · · · · · · · · · · ·	K. Y. and Z dired	ctions	
Shock resistance		150 m/s² (100 m/s² for relay outputs) 3 times each in 3 axes, 6 directions							
Weight		Approx. 300 g (Base Unit only)							
Degree of	Front panel			ndoor use (equival	ent to IP66)				
protection	Rear case	IP20		· · · · · · · · · · · · · · · · · · ·	•				
	Terminals	IP00 + finger protection (VDE0106/100)							
Memory protection		EEPROM (non-volatile memory) Number of rewrites: 100.000							
Applicable standard	ds	UL61010C-1, CSA C22.2 No. 1010.1 (evaluated by UL) EN61010-1 (IEC61010-1): Pollution degree 2/Overvoltage category II EN61326: 1997, A1: 1998, A2: 2001							
EMC		EMI: EN61326+A1 industrial applications Electromagnetic radiation interference CISPR 11 Group 1, Class A: CISPRL16-1/-2 Terminal interference voltage CISPR 11 Group 1, Class A: CISPRL16-1/-2 EMS: EN61326+A1 industrial applications Electrostatic Discharge Immunity EN61000-4-2: 4 kV (contact), 8 kV (in air) Radiated Electromagnetic Field Immunity EN61000-4-3: 10 V/m 1 kHz sine wave amplitude modulation (80 MHz to 1 GHz, 1.4 to 2 GHz) Electrical Fast Transient/Burst Immunity EN61000-4-4: 2 kV (power line), 1 kV (I/O signal line) Surge Immunity EN61000-4-5: 1 kV with line (power line), 2 kV with ground (power line) Conducted Disturbance Immunity EN61000-4-6: 3 V (0.15 to 80 MHz) Power Frequency Magnetic Immunity EN61000-4-8: 30 A/m (50 Hz) continuous time Voltage Dips and Interruptions Immunity EN61000-4-11: 0.5 cycle, 0°/180°, 100% (rated voltage)							

## **Operation**

## **■** Functions (Operating Modes)

#### F1 to F3

Function name	Function No.
Individual inputs	F!
Phase differential inputs	F2
Pulse counting input	F3



Note: 1. Meaning of H and L in Display

Symbol	Input method	No-voltage input
Н		Short-circuit
L		Open

2. Requires at least half the minimum signal width. If there is less than half, a ±1 count error may occur.

#### Input Type Setting

	NO: Voltage pulse high	NC: Voltage pulse low
No-contact or voltage pulse input	00	0 !
Contact	10	11

## ■ What Is Prescaling?

Prescaling converts the count value to any numeric value.


To display  $\square\square\square\square.\square$  mm in a system that outputs 250 pulses for a 0.5-m feed,

the length per pulse =  $500 \text{ mm} (0.5 \text{ m}) \div 250 = 2.$ 

1. The prescale value for the K3HB-C is set using the mantissa  $X\times$  exponent Y, so the prescale value = 2.0000  $\times$  10°,

X = 2.000, and Y = 00.

2. Next, set the decimal point position for one digit to the right of the decimal point: acac.a



## **Common Specifications**

## **■ Event Input Ratings**

K3HB-R	S-TMR, HOLD, RESET, BANK1, BANK2, BANK4					
K3HB-P/-C	HOLD, RESET, BANK1, E	BANK2, BANK4				
Contact	ON: 1 k $\Omega$ max., OFF: 100 k $\Omega$ min.					
No-contact	ON residual voltage: 2 V max.					
	OFF leakage current: 0.1 mA max.					
	Load current: 4 mA max.					
	Maximum applied voltage: 30 VDC max.					

## **■** Output Ratings

## **Contact Output**

Item	Resistive loads (250 VAC, cos\u00f3=1; 30 VDC, L/R=0 ms)	Inductive loads (250 VAC, closed circuit, cos∳=0.4; 30 VDC, L/R=7 ms)		
Rated load	5 A at 250 VAC 5 A at 30 VDC	1 A at 250 VAC 1 A at 30 VDC		
Rated through current	5 A			
Mechanical life expectancy	5,000,000 operations			
Electrical life expectancy	100,000 operations			

## **Transistor Outputs**

Maximum load voltage	24 VDC
Maximum load current	50 mA
Leakage current	100 μA max.

## **Linear Output**

Item	Outputs	0 to 20 mA	4 to 20 mA	0 to 5 V	1 to 5 V	0 to 10 V
Allowable load impedance 500 $\Omega$ max.		500 $\Omega$ max.		5 k $Ω$ min.		
Resolution		Approx. 10,000	)			
Output error		±0.5% FS		±0.5% FS (±0.15 V for 1	V or less and no	output for 0 V)

## **Serial Communications Output**

Item Type	RS-232C, RS-485
Communications method	Half duplex
Synchronization method	Start-stop synchronization (asynchronous)
Baud rate	9600/19200/38400 bps
Transmission code	ASCII
Data length	7 bits or 8 bits
Stop bit length	2 bits or 1 bit
Error detection	Vertical parity and FCS
Parity check	Odd, even

## BCD Output I/O Ratings (Input Signal Logic: Negative)

I/O signal name			Item		Rating
Inputs	<b>K3HB-R/P</b> REQUEST REQUEST		Input signal		No-voltage contact input
MAX SA	COMPEN- SATION		urrent for age input	10 mA	
	MIN RESET	RESET	Signal level	ON voltage	1.5 V max.
	TILOLI	)E1		OFF voltage	3 V min.
Outputs	Outputs DATA POLARITY OVER DATA VALID		Maximum load voltage		24 VDC
			Maximum load current		10 mA
	RUN		Leakage current		100 μA max.
	K3HB-R/P HH	K3HB-C OUT1	Maximum load voltage		24 VDC
	OUT2 OUT3	Maximum load current		50 mA	
	L OUT4 LL OUT5		Leakage current		100 μA max.

Refer to the *K3HB Communications User's Manual* (Cat. No. N129) for details on serial and DeviceNet communications.


## **DeviceNet Communications**

Communications protocol		Conforms to DeviceNet					
communications	Remote I/O communications	Master-Slave connection (polling, bit-strobe, COS, cyclic)					
		Conforms to DeviceNet communications standards.					
	I/O allocations	Allocate any I/O data using the Configurator.  Allocate any data, such as DeviceNet-specific parameters and variable area for Digital Indicators					
		Input area: 2 blocks, 6	0 words max.				
		Output area: 1 block, 29 words max. (The first word in the area is always allocated for the Output Execution Enabled Flags.)					
	Message	Explicit message com	munications				
	communications	CompoWay/F communication (using explicit message)		can be executed			
Connection meth	ods	Combination of multi-drop and T-branch connections (for trunk and drop lines)					
Baud rate		DeviceNet: 500, 250, or 125 Kbps (automatic follow-up)					
Communications media		Special 5-wire cable (2 signal lines, 2 power supply lines, 1 shield line)					
Communications distance		Baud rate	Network length (max.)	Drop line length (max.)	Total drop line length (max.)		
		500 Kbps	100 m max. (100 m max.)	6 m max.	39 m max.		
		250 Kbps	100 m max. (250 m max.)	6 m max.	78 m max.		
		125 Kbps	100 m max. (500 m max.)	6 m max.	156 m max.		
		The values in parentheses are for Thick Cable.					
Communications power supply		24-VDC DeviceNet power supply					
Allowable voltage fluctuation range		11 to 25-VDC DeviceNet power supply					
Current consumption		50 mA max. (24 VDC)					
Maximum number of nodes		64 (DeviceNet Configurator is counted as one node when connected.)					
Maximum number of slaves		63					
Error control che	cks	CRC errors					
DeviceNet power	eNet power supply Supplied from DeviceNet communications connector						

## **Connections**

## ■ External Connection Diagrams


#### **Terminal Arrangements**




insulation for the DeviceNet power supply.

The product must be used indoors for the above applicable standards to apply.


<FLK3A>



- Models with Terminal Blocks <1> <3> <2> <4> 2: S-TMR 4: RESET 1: N/C 1: N/C 3: HOLD 5: COMPENSATION (D) N/C 6: COM 0 S-TMR 9 8: BANK2 10 10: COM 7: BANK4 9: BANK1 €3 HOLD Applicable Connector (Sold separately) (A) RESET XG4M-1030 (OMRON) Special Cable (Sold separately)
  K32-DICN (OMRON) COMPENSATION **6** (XG4M-1030 with 3-m cable) 6 COM The following signals depend on the model: S-TMR: Used by the K3HB-R only. COMPENSATION: Used by the K3HB-C only
- for event input.



### **BCD Output Cable**




Note: The BCD Output Cable has a D-sub plug. Cover: 17JE-37H-1A (manufactured by DDK); Connector: equivalent to 17JE-23370-02 (D1) (manufactured by DDK)

## Special Cable (for Event Inputs with 8-pin Connector)

Model	Appearance	w	Wiring	
K32-DICN	9 10 2 3,000 mm_ Cable marking (3 m)	1 2 3 4 5 5 6 7 8	ignal name N/C S-TMR HOLD RESET N/C COM BANK4 BANK2 BANK1 COM	


## ■ Derating Curve for Sensor Power Supply (Reference Values)

#### For 12V



- **Note: 1.** The above values were obtained under test conditions with the standard mounting. The derating curve will vary with the mounting conditions, so be sure to adjust accordingly.
  - 2. Internal components may be deteriorated or damaged. Do not use the Digital Indicator outside of the derating range (i.e., do not use it in the area labeled (1), above).


## **■** Internal Block Diagram



## **■** BCD Output Timing Chart


A REQUEST signal from a Programmable Controller or other external device is required to read BCD data.

#### **Single Sampling Data Output**



The data is set in approximately 30 ms from the rising edge of the REQUEST signal and the DATA VALID signal is output. When reading the data from a Programmable Controller, start reading the data when the DATA VALID signal turns ON. The DATA VALID signal will turn OFF 40 ms later, and the data will turn OFF 16 ms after that.


#### **Continuous Data Output**




Measurement data is output every 64 ms while the REQUEST signal remains ON.

Note: If HOLD is executed when switching between data 1 and data 2, either data 1 or data 2 is output depending on the timing of the hold signal. The data will not go LOW.

• The K3HB BCD output model has an open collector output, so wired OR connection is possible






Note: Leave 20 ms min. between DATA VALID turning OFF and the REQUEST signal.

## **Programmable Controller Connection Example**

#### **Display Unit Connection Example**




the BCD Output Cable (sold separately) is connected. This number differs from the pin number for the Digital Indicator narrow pitch connector (manufactured by Honda Tsushin Kogyo Co., Ltd.).


Refer to the following User's Manual for application precautions and other information required when using the Digital Indicator: K3HB-R/P/C Digital Indicator User's Manual (Cat. No. N136)

The manual can be downloaded from the following site in PDF format: OMRON Industrial Web http://www.fa.omron.co.jp

## **■** Component Names and Functions



#### ■ Dimensions




#### **Wiring Precautions**

- For terminal blocks, use the crimp terminals suitable for M3 screws.
- Tighten the terminal screws to the recommended tightening torque of approx. 0.5 N⋅m.
- To prevent inductive noise, separate the wiring for signal lines from that for power lines.

#### **Wiring**

• Use the crimp terminals suitable for M3 screws shown below.



## **Unit Stickers (included)**


- No unit stickers are attached to the Digital Indicator.
- Select the appropriate units from the unit sticker sheets provided.




Note: For measurements for commercial purposes, be sure to use the unit required by any applicable laws or regulations.

#### **Mounting Method**

- 1. Insert the K3HB into the mounting cutout in the panel.
- Insert watertight packing around the Unit to make the mounting watertight.




Insert the adapter into the grooves on the left and right sides of the rear case and push until it reaches the panel and is fixed in place.



#### **LCD Field of Vision**

The K3HB is designed to have the best visibility at the angles shown in the following diagram.



## **Waterproof Packing**

The waterproof packing ensures a level of waterproofing that conforms to NEMA 4X. Depending on the operating environment, deterioration, contraction, or hardening may occur and replacement may be necessary. In this case, consult your OMRON representative.

## **Main Functions**

#### ■ Main Functions and Features

#### Measurement

#### **Function** FUn[ RPC

The K3HB-R has the following six functions for receiving and displaying input pulses.

F1: Rotation (rpm)/circumferential speed

F2: Absolute ratio

F3: Error ratio

F4: Rotational difference

F5: Flow rate ratio

F6: Passing time

The K3HB-P has the following six functions for receiving and displaying input pulses.

F1: Passing speed

F2: Cycle

F3: Time difference

F4: Time band

F5: Measuring length

F6: Interval

The K3HB-C has the following three functions for receiving and displaying input pulses.

F1: Individual inputs

F2: Phase differential inputs

F3: Pulse counting input

#### **Filters**

## Average Processing Auti-L. Auti-n R

Average processing of input signals with extreme changes or noise smooths out the display and makes control stable.



Specify the types of sensor connected to input A and input B.

#### **Input Compensation**

#### **Auto-zero Times**

REIR, REIB R

The frequency is forced to zero if there is no pulse input for a set period.

#### **Input Compensation**

CăăPa. Căă-P C



The display can be changed to a preset compensation value using the compensation input.

#### **Key Operations**

#### **Teaching**



The present measurement value can be used as a scaling value.

#### **Key Protection**





Key protection restricts level or parameter changes using the keys to prevent unintentional key operations and malfunctions.

#### **Outputs**

#### Comparative Output Pattern 644-P R P C

Standard, zone, and level comparative output patterns can be selected for comparative outputs.

#### **Hysteresis**

HYS R

Prevents comparative outputs from chattering when the measurement value fluctuates slightly near the set value.

#### Output Refresh Stop 6-5kP R P

Holds the output status when a comparative result output other than PASS turns ON.

#### PASS Output Change PR55 R P



Comparative results other than PASS and error signals can be output from the PASS output terminal.

#### **Output OFF Delay**

öff-d R P C

Delays turning OFF comparatives for a set period. This can be used to provide sufficient time to read the comparative output ON status when the comparative result changes at short intervals.

#### **Shot Output**



SHOLE R P C

Turns ON the comparative output for a specific time.

#### **Output Logic**

åUt-n R P C





Reverses the output logic of comparative results.

#### Startup Compensation Timer 5-60 R



Measurements can be stopped for a set time using an external input.

#### Output Test



Output operation can be checked without using actual input signals by using the keys to set a test measurement value.

#### **Linear Outputs**

LSEEL, LSEEL, LSEEH, LSEEL



A current or voltage proportional to the change in the measurement value can be output.

#### **Standby Sequence**



The comparison outputs can be kept OFF until the measurement value enters the PASS range.

#### Display

#### Display Value Selection disp R P C



The display value can be set to the present value, the maximum value, or the minimum value.

#### **Display Color Selection**

Color RPC



The present value display color can be set to green or red. The color of the present value can also be switched according to the comparative output.

#### Display Refresh Period dref R P C



When the input changes rapidly, the display refresh period can be lengthened to control flickering and make the display easier to read.

#### **Position Meter**

PõS-Ł. PõS-H. PõS-L

The present measurement value can be displayed as a position in relation to the scaling width on a 20-gradation position meter.

#### **Prescale**

PS.R.J., PS.RY., PS.b.J., PS.b.Y

The input signal can be converted and displayed as any value.

#### Comparative Set Value Display 50.05P R P C





Select whether or not to display the comparative value during operation.

#### Display auto-return





Automatically returns the display to RUN level when there are no key operations (e.g., max./min. switching, bank settings using keys).

#### Other

#### Max./Min. Hold

Holds the maximum and minimum measurement values.

#### **Bank Selection**



bnY-[ RPC

Switch between 8 comparative value banks using the keys on the front panel or external inputs. A set of set comparative values can be selected as a group.

#### **Bank Copy**



Any bank settings can be copied to all banks.

#### Interruption Memory

ňEňa C

The measured value can be recorded when the power supply is interrupted.

#### User Calibration

The K3HB can be calibrated by the user.

## **Common Precautions**

#### ■ Precautions

#### / WARNING

Do not touch the terminals while power is being supplied. Doing so may possibly result in electric shock. Make sure that the terminal cover is installed before using the product.



Always provide protective circuits in the network. Without protective circuits, malfunctions may possibly result in accidents that cause serious injury or significant property damage. Provide double or triple safety measures in external control circuits, such as emergency stop circuits, interlock circuits, or limit circuits, to ensure safety in the system if an abnormality occurs due to malfunction of the product or another external factor affecting the product's operation.



#### **∕!\ CAUTION**

Do not allow pieces of metal, wire clippings, or fine metallic shavings or filings from installation to enter the product. Doing so may occasionally result in minor electric shock, fire, or malfunction.



Do not use the product in locations where flammable or explosive gases are present. Doing so may occasionally result in minor or moderate explosion, causing minor or moderate injury, or property damage.



Do not attempt to disassemble, repair, or modify the product. Doing so may occasionally result in minor or moderate injury due to electric shock.



Do not use the equipment for measurements within Measurement Categories II, III or IV (according to IEC61010-1). Doing so may occasionally cause unexpected operation, resulting in minor or moderate injury, or damage to the equipment. Use the equipment for measurements only within the Measurement Category for which the product is designed.



Perform correct setting of the product according to the application. Failure to do so may occasionally cause unexpected operation, resulting in minor or moderate injury, or damage to the equipment.



Ensure safety in the event of product failure by taking safety measures, such as installing a separate monitoring system. Product failure may occasionally prevent operation of comparative outputs, resulting in damage to the connected facilities and equipment.



Tighten the screws on the terminal block and the connector locking screws securely using a tightening torque within the following ranges. Loose screws may occasionally cause fire, resulting in minor or moderate injury, or damage to the equipment.



Terminal block screws: 0.43 to 0.58 N⋅m Connector locking screws: 0.18 to 0.22 N⋅m

Make sure that the product will not be adversely affected if the DeviceNet cycle time is lengthened as a result of changing the program with online editing. Extending the cycle time may cause unexpected operation, occasionally resulting in minor or moderate injury, or damage to the equipment.



Before transferring programs to other nodes or changing I/O memory of other nodes, check the nodes to confirm safety. Changing the program or I/O memory of other nodes may occasionally cause unexpected operation, resulting in minor or moderate injury, or damage to the equipment.




#### **Precautions for Safe Use**

- 1. Do not use the product in the following locations.
  - Locations subject to direct radiant heat from heating equipment
  - Locations where the product may come into contact with water or oil
  - · Locations subject to direct sunlight
  - Locations where dust or corrosive gases (in particular, sulfuric or ammonia gas) are present
  - · Locations subject to extreme temperature changes
  - · Locations where icing or condensation may occur
  - · Locations subject to excessive shocks or vibration
- 2. Do not use the product in locations subject to temperatures or humidity levels outside the specified ranges or in locations prone to condensation. If the product is installed in a panel, ensure that the temperature around the product (not the temperature around the panel) does not go outside the specified range.
- 3. Provide sufficient space around the product for heat dissipation.
- 4. Use and store the product within the specified temperature and humidity ranges. If several products are mounted side-by-side or arranged in a vertical line, the heat dissipation will cause the internal temperature of the products to rise, shortening the service life. If necessary, cool the products using a fan or other cooling method.
- 5. The service life of the output relays depends on the switching capacity and switching conditions. Consider the actual application conditions and use the product within the rated load and electrical service life. Using the product beyond its service life may result in contact welding or burning.
- 6. Install the product horizontally.
- 7. Mount to a panel between 1 and 8-mm thick.
- 8. Use the specified size of crimp terminals (M3, width: 5.8 mm max.) for wiring. To connect bare wires, AWG22 (cross section: 0.326 mm²) to AWG14 (cross section: 2.081 mm²) to wire the power supply terminals and AWG28 (cross section: 0.081 mm²) to AWG16 (cross section: 1.309 mm²) for other terminals. (Length of exposed wire: 6 to 8 mm)
- 9. In order to prevent inductive noise, wire the lines connected to the product separately from power lines carrying high voltages or currents. Do not wire in parallel with or in the same cable as power lines. Other measures for reducing noise include running lines along separate ducts and using shield lines.
- **10.**Ensure that the rated voltage is achieved no longer than 2 s after turning the power ON.
- **11.** Allow the product to operate without load for at least 15 minutes after the power is turned ON.
- 12.Do not install the product near devices generating strong high-frequency waves or surges. When using a noise filter, check the voltage and current and install it as close to the product as possible.
- 13.Do not use thinner to clean the product. Use commercially available alcohol.
- **14.**Be sure to confirm the name and polarity for each terminal before wiring the terminal block and connectors.
- 15. Use the product within the noted supply voltage and rated load.
- 16.Do not connect anything to unused terminals.
- 17.Output turns OFF when the mode is changed or settings are initialized. Take this into consideration when setting up the control system.
- 18.Install an external switch or circuit breaker that complies with applicable IEC60947-1 and IEC60947-3 requirements and label them clearly so that the operator can quickly turn OFF the power.
- 19.Use the specified cables for the communications lines and stay within the specified DeviceNet communications distances. Refer to the User's Manual (Cat. No. N129) for details on communications distance specifications and cables.

- **20.**Do not pull the DeviceNet communications cables with excessive force or bend them past their natural bending radius.
- 21.Do not connect or remove connectors while the DeviceNet power is being supplied. Doing so will cause product failure or malfunction.
- 22.Use cables with heat resistance of 70°C min.


#### **■** Noise Countermeasures

- Do not install the product near devices generating strong highfrequency waves or surges, such as high-frequency welding and sewing machines.
- Mount a surge suppressor or noise filter to peripheral devices generating noise, in particular, motors, transformers, solenoids, and magnet coils.



3. In order to prevent inductive noise, wire the lines connected to the terminal block separately from power lines carrying high voltages or currents. Do not wire in parallel with or in the same cable as power lines. Other measures for reducing noise include running lines along separate ducts and using shield lines.

## **Example of Countermeasures for Inductive Noise on Input Lines**



- 4. If a noise filter is used for the power supply, check the voltage and current, and install the noise filter as close to the product as possible.
- 5. Reception interference may occur if the product is used close to a radio, television, or wireless.

## **Warranty and Limitations of Liability**

#### **■ WARRANTY**

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES. EXPRESS OR IMPLIED.

#### **■ LIMITATIONS OF LIABILITY**

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS, OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE. OR STRICT LIABILITY.

In no event shall the responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

## **Application Considerations**

#### **■ SUITABILITY FOR USE**

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the products.

At the customer's request, OMRON will provide applicable third party certification documents identifying ratings and limitations of use that apply to the products. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products.

- Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this catalog.
- Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.
- Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCTS ARE PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

#### ALL DIMENSIONS SHOWN ARE IN MILLIMETERS.

To convert millimeters into inches, multiply by 0.03937. To convert grams into ounces, multiply by 0.03527.

Cat. No. N135-E1-02 In the interest of product improvement, specifications are subject to change without notice.

## **OMRON Corporation**

**Industrial Automation Company** 

Industrial Devices and Components Division H.Q. Measuring Components Department Shiokoji Horikawa, Shimogyo-ku, Kyoto, 600-8530 Japan Tel: (81)75-344-7080/Fax: (81)75-344-7189